
#### Towbar accessories:





# PPUH AUTO-HAK S.J.

Produkcja Zaczepów Kulowych Henryk & Zbigniew Nejman 76-200 SŁUPSK ul. Słoneczna 16K tel/fax (059) 8-414-414; 8-414-413 E-mail: <u>office@autohak.com.pl</u> www. autohak.com.pl

## Towing hitch (without electrical set)

Class: A50-X Cat. no. W08 Designed for: Manufacturer: SUZUKI Model: GRAND VITARA Type: 3/5 door produced since 09.1998 till 2005 and Model: GRAND VITARA XL-7 produced since 2001 till 2006

Technical data: D-value: 10,43 kN maximum trailer weight: 1850 kg maximum vertical cup load: 80 kg

#### Approval number acc. to regulations EKG/ONZ 55.01: E20-55R-01 1249

#### Foreword


This towbar is designed according to rules of safety traffic regulations. The towing hitch is a safety component and can be install only by qualified personnel. Any alteration or conversion of the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch. The vehicle manufacturer's specifications regarding trailer load and max. vertical

cup load are decisive for driving whereat values for the towing hitch cannot be exceeded.

D-value formula:

$$\frac{\text{Max trailer weight [kg]}}{\text{Max trailer weight [kg]}} \times \frac{\text{Max vehicle weight [kg]}}{\text{Max trailer weight [kg]}} \times \frac{9,81}{1000} = D [kN]$$

### FITTING INSTRUCTION



This towbar is designed to assembly in following cars: **SUZUKI GRAND VITARA, 3/5 door,** produced since 09.1998 till 2005 and **SUZUKI GRAND VITARA XL-7** produced since 2001 till 2006, catalogue no. **W08** and is prepared to tow trailers max total weight **1850 kg** and max vertical load **80 kg**.

#### From manufacturer

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towbar depends also on correct assembly and right operation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

The towbar should be install in points described by a car producer.

## The instruction of the assembly

- 1. Unscrew original towing eye, not used any more.
- 2. Put the main bar of the towbar (pos. 1) from below the car to chassis and through holes (pos. A) and existing in chassis threaded holes fix using bolts M12x1,25x35mm (pos. 5) from accessories.
- 3. To so prepared towbar fix tow-ball (pos. 2) with socket plate (pos. 3) using bolts M12x75mm (pos. 4) from accessories.
- 4. Tighten all bolts according to the torque shown in the table.
- 5. Connect electric wires of 7-poles socket according to the instruction of the car. (Recommend to make at authorized service station).
- 6. Complete paint layer damaged during installation.

Torque settings for nuts and bolts (8,8):		
<b>M6 -</b> 11 Nm	<b>M 8 -</b> 25 Nm	<b>M 10 -</b> 50 Nm
<b>M 12 -</b> 87 Nm	<b>M 14 -</b> 138 Nm	<b>M16</b> - 210 Nm

### NOTE

After install the towbar you should get adequate note in registration book (at authorised service station). The car should be equipped with:

- Indicators
- Tow mirrors

After 1000km of exploitation check all bolts and nuts. The ball of towbar must be always kept clear and conserve with a grease.